


NOTE:

- 1) PIPE LESS THAN OR EQUAL TO 12"Ø
MUST USE 3/4" CORP. STOP, ANGLE BALL VALVE
AND SERVICE PIPE.
- 2) PIPE GREATER THAN 12"Ø TO USE
1" CORP. STOP, ANGLE BALL VALVE
AND SERVICE PIPE.

MANUAL AIR RELEASE
VALVE DETAIL



BUTLER COUNTY
WATER AND SEWER

130 HIGH STREET
HAMILTON, OH 45011
TELEPHONE: 513-887-3066
FAX: 513-887-3777